

• **Step # 1**

All horizontal fire barriers must be installed first. \*Note\* if you installed a Fireline 520 floor to wall pre made 90, look for Box #1 you will be starting with a male end putting it into the female end of the 90 the female end will be facing up.

• **Step # 2**

Review Fireline 520 approved shop drawing Fig # 3

• **Step # 3**

Install # 1 fire barrier mark # 1 in box #1 use your spreader 3 tools and push the fire barrier tight to the wall,

• **Step #4**

Anchor fire barrier to wall (apply dry wall screws to both sides of the fire barrier 12" on center, after applying all screws remove all spreader tools from the first fire barrier). You are ready for blanket #2

• **Step #5**

Install blanket #2 insert male end into the female end of blank #1, make sure male end fits tight to blanket #1, install 3 spreader tools in to blanket #2 and push to make blanket 2 tight to the wall see detail drawing, follow same steps all the way up the wall

• **Step #6**

Fireline 520 wallguard fire barriers were tested without fire caulk, you must keep the last fire barrier tight to the sub straight, and you may apply fire caulk on the end blanket in the field if needed. Caulk is not supplied by Fireline 520,